

## **RFI CHECKLIST**

Verify that the question being asked is not already located on the plans and specs.
Provide within the RFI all plan and specification references associated with it.
Make sure you understand all information contained within the RFI. If there is something you do not understand, clarify/research that BEFORE you send.
Provide a detailed narrative that will allow the design team to respond accurately and without follow-up.
Provide a "proposed solution" with every RFI.
Do not "cry wolf" with urgent RFIs. If an RFI is urgent, make sure you explain exactly why and the effect of a slow response. Otherwise, give the design professional the standard 7 calendar days to respond.
Spell check and reconfirm all plan references.
Assign your request to the same designated design contact every time.
Make sure the response back is appropriate and accurate before subcontractor distribution.
Post the RFI response to the as-builts (see As-Builts).

